

Platinum Center Angle Adjustment

A tilting mechanism built into the feet of the speaker allows the cabinet to be tilted up or down 4°. The baffle has a built in angle of 8°, thus the adjustment range for the speaker is 4° - 12°.

To adjust the angle of the speaker:

- Adjust the right foot by inserting the tool supplied with the speaker into the grill pin socket in the bottom right corner of the speaker until it engages with the adjustment screw (about 1 3/4"). Rotate the adjustment screw **Clockwise to Lower** the front of the speaker and reduce the angle, or **Counterclockwise to Raise** the front of the speaker and increase the angle.
- Adjust the left foot in the same manner using the adjustment screw behind the grill pin socket in the bottom left corner of the speaker.
- Adjust both feet the same amount to ensure that the speaker sits squarely on all four feet.

The feet also incorporate a self-leveling feature that will compensate for slight misalignment of the left and right tilting mechanisms.

